




# STM Exercise 7


Phase Diagrams  
(partial solubility in the solid state)

Sara Ferraris  
sara.ferraris@polito.it


Complete solubility in the liquid state,  
partial solubility in the solid state




Exercise 1: determine the phase present, their composition and relative amounts in the points **A**, **B**, **C** (at the beginning of the eutectic transformation), **D** (at the end of the eutectic transformation) and **E** indicated in the phase diagram. Schematize the microstructure in each point.



Exercise 2: determine the phase present, their composition and relative amounts in the points A, B, C, D, E and F indicated in the phase diagram. Schematize the microstructure in each point.




**E.6** Use the Pb-Sn diagram below to answer the following questions.




- (a) What are the values of the state variables (composition and temperature) at constitution point 1?
- (b) Mark the constitution points for Pb-60wt% Sn and Pb-20wt% Sn alloys at 250°C. What phases are present in each case?
- (c) The alloy at constitution point 1 is cooled very slowly to room temperature, maintaining equilibrium. At which temperatures do changes in the number or type of phases occur? What phases are present at constitution points 2 and 3?
- (d) The alloy at constitution point 4 is cooled slowly to room temperature. Identify the following:
  - (i) the initial composition, temperature and phase(s);
  - (ii) the temperature at which a phase change occurs, and the final phase(s).

**E.7** Use the Pb-Sn diagram below to answer the following questions.



- (a) The constitution point for a Pb-25wt% Sn alloy at 250 °C lies in a two-phase field. Construct a tie-line on the figure and read off the two phases and their compositions.
- (b) The alloy is slowly cooled to 200 °C. At this temperature, identify the phases and their compositions
- (c) The alloy is cooled further to 150 °C. At this temperature, identify the phases and their compositions.
- (d) Indicate with arrows on the figure the lines along which the compositions of phase 1 and phase 2 move during slow cooling from 250°C to 200°C.




Consider Pb-20wt% Sn at 250  $^{\circ}\text{C}$  in Figure

A constitution point in the two-phase field: liquid plus Pb-rich solid.


**Find the proportions of each phase**

Determine the phase/s present, the composition/s and relative amount/s for an alloy with 50%Ti at 1100°C.






Complete the following diagram



Complete the following diagram



**Figura 9.19** Diagramma di fase rame–zinco.



William D. Callister Jr., David G. Rethwisch  
Scienza ed Ingegneria dei Materiali  
EdiSES